



BASE SIZE WITH SPACERS	ADJUSTERS + NUTS (32MM EACH SIDE)	FINAL SIZE WITH ADJUSTERS	FULL ADJUSTMENT	SPACERS
1490	65	1555	1645	LARGE
1415	65	1480	1570	SMALL

VEHICLE MAKE	LOAD BAY WIDTH	SPACERS TO USE
BYD SHARK	1520	SMALL
FORD RANGER	1565	LARGE
FORD RANGER NEXT GEN	1570	LARGE
FORD RANGER NEXT GEN RAPTOR + WILDTRAK + PREMIUM	1500	SMALL
GWM P SERIES P20 / P300 / P500	1520	SMALL
ISUZU D MAX	1540	SMALL
JAC	1560	LARGE
MAHINDRA	1520	SMALL
MAZDA BT50	1590	LARGE
MITSUBISHI TRITON	1545	SMALL
NISSAN NAVARA	1565	LARGE
TOYOTA HILUX	1580	LARGE
VW AMAROK	1640	LARGE
VW AMAROK NEXT GEN	1520	SMALL

Selecting the correct size Work Buddy for your vehicle:

Prior to fitting you Work Buddy, please double check the width of your vehicle to the correct spacers are applied to your Work Buddy. This can be done by measuring the internal width of your vehicle's loading bay.

- Should your vehicle's internal width measure between 1480mm-1560mm the smaller spacers need to be used on the sides of the unit.
- Should your vehicle's internal width be 1560mm-1650mm the larger spacers need to be used on the sides of the unit.

