





Before changing the Electrical Resistance, turn the general electrical switch off, or the switch that solely commands FAME Electronic Intense electrical circuit.


Close the gauge of the pipeline where the device is installed.




Press both side buttons of the shower to unlock the Intense Shower cover.




The Cover unlocks in the places indicated in the figure.



After unlocking, pull the Electronic Intense Shower cover, releasing it completely.





Unscrew the heating assembly Cover **counterclockwise**.




When removing the damaged Electrical Resistance, pull it by the tab indicated in figure (4a).

To facilitate the removal of the damaged piece.




Wipe and clean the electrical contact areas and fit the new Electrical Resistance.




Before closing the heating assembly, make sure the trim is appropriately fitted around the heating assembly cover.




Fit the heating assembly cover.



Screw the heating assembly cover **clockwise**.



Fit the lower sides of the Intense Shower Cover at the area indicated in figure 9.



Subsequently, press the Intense Shower upper lock to conclude the process.



FAME - Fábrica de Aparelhos e
Material Elétrico Ltda.

Rua Cajuru, 746 - Belenzinho - São Paulo - SP
CEP 03057-900- CNPJ: 60.620.366/0001-95
Indústria Brasileira

If you need further information,
contact us through our Call Center:

0800 - 015 85 00 option 2 for SAC

SAC SERVIÇO DE ATENDIMENTO
AO CONSUMIDOR FAME
sac@fame.com.br - www.fame.com.br